ADVANCED HIGH CEILING Whiz Bidirectional - Adjustable Aircraft Cable








IMPORTANT SAFETY INFORMATION. **READ AND FOLLOW ALL SAFETY INSTRUCTIONS**

IMPORTANT SAFETY INFORMATION. READ AND FOLLOW ALL SAFETY INSTRUCTIONS. Before wiring to power supply and during servicing or relamping, turn off power at fuse or circuit breaker. All servicing or relamping must be performed by qualified service personnel. Product must be grounded to avoid potential electric shock or other potential hazard. Product must be at locations and at heights and in a manner consistent with its intended use, and in compliance with Electrical Code and local codes.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.







Step 1


Secure bracket to level surface with mounting hardware that is sufficient to support weight of LED fixture and power box.

Step 2

Secure power supply box to bracket with provided screws.


ADVANCED HIGH CEILING Whiz Bidirectional - Adjustable Aircraft Cable






Step 3

Screw in and secure the other ring hook onto the top side of the light fixture. Connect the pendant cable to the ring hook on the light fixture.




Step 4

Secure the ring hook using a lock nut onto the bottom side of the bracket. One side of the pendant cable connects to the ring hook on the bracket.



Step 5

Connect power input wires with corresponding black/white/green wires using attached connector at the end of the wires.



Step 6

Finished and make sure all screws are tightly secured.


ADVANCED HIGH CEILING





Wiring Diagram

Standard 0-10V: Single Dimming Switch (Controls up and down dimming together)



Optional 0-10V: Dual Dimming Switch: Controls up and down dimming separately

